



RIO Tronics NT10-4P-CF-I WaterRead

Installation Instructions

Remove register box seal pin

Remove register box, place **RIO Tronics WaterRead** onto meter body and turn to engage

Replace register box on top of **WaterRead** unit, and turn to engage

Replace register box seal pin and add seal screw to **WaterRead** device, T25 Torx Tamperproof screw

Wire connections are red and black to digital inputs of host logging device, bare wire is optional ground. For specifications of output see product literature

Test with multimeter to see 100 ohms and infinite ohms on red and black wires for each output

